

ASSEMBLY INSTRUCTIONS

Item No: 61468

Description: 3-DRWR NIGHTSTAND - LANGHAM NAT

Item No: 61568

Description: 3-DRWR NTSTAND - LANGHAM WHITE

Item No: 61668

Description: 3-DRWR NTSTAND - LANGHAM BLACK



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

ASSEMBLY PROCEDURE:

Step 1. Place the Nightstand (A) on its back, on a clean and soft surface. Attach the Bun Feet (B) to the bottom corners of the Nightstand.

Step 2. Carefully set the Nightstand upright.

PARTS LIST:

No.	Description	Sketch	Quantity
A	Nightstand		1 pc
B	Bun Foot		4 pcs

