



Carpet Base

INSTALLATION INSTRUCTIONS

REQUIRED EQUIPMENT

The following items may be purchased from a local carpet workroom supplier:

- Razor knife
- Straight edge/square
- Cove base adhesive
- 3/32" trowel or caulk gun with nozzle

GENERAL INSTALLATION PROCEDURES

1. Ensure that all pile direction is running in the same direction. This is important to keep a consistent look.
2. Unroll base next to the wall, face down.
3. Apply adhesive to the back of the carpet being careful not to get within ¼" of the carpet base edge.
4. Start the installation of the base in a corner or at a door frame by firmly pressing the carpet base in place to ensure the adhesive is making solid contact. Continue working the base to the wall by putting a slight stretch on the base to prevent wrinkles.
5. Inside corners may be cut or pressed firmly into the corner. Outside corners should be wrapped around. Extra adhesive may be required on outside corners.
6. Carpet base should be cut from the back with a straight edge or framing square. When cutting, place the piece on top of cardboard or wood to prevent damage to the existing flooring.
7. Carpet base should be cut flush with door frames.

If the base is stapled to the wall, indentions may be visible. Mohawk does not recommend this method of installation.

This information, offered as a customer service, is based on Mohawk Group's engineering tests and field experience. It is intended for installers with professional experience, to be used at their discretion and risk. The Mohawk Group does not guarantee results and assumes no liability in connection with these installation instructions.

160 South Industrial Blvd.
Calhoun, GA. 30701
MohawkGroup.com

Technical Services Department
196 S. Industrial Blvd.
Calhoun, GA 30701
800.833.6954
ssproductinfo@mohawkind.com