

FLYNN WOOD 1 DRAWER NIGHTSTAND

INTRODUCTION


Enclosed please find simple step-by-step instructions to help you quickly assemble your product. Before you begin, we recommend that you follow the steps below:

1. Please read the instructions thoroughly
2. Identify all parts and hardware
3. Gather the tool(s) necessary
4. Two adults required for assembly

To protect your parts during assembly please place them on a soft surface. To clean surface use only water on a damp cloth. Do not use window cleaners or cleaning abrasives as it will scratch the surface and could damage the protective coating.






CUSTOMER SUPPORT

If you are missing parts or need assistance with your product, please contact the retailer from whom you purchased the product. When you call or email, please include the Product's Item Number and PO Number which is located on the Production Tracking Sticker. This sticker can be found on the bottom, inside or back of your product.




PARTS LIST





HARDWARE FOR NIGHT STAND

A		M6x55mm Bolts X 4
B		M6x35mm Bolts X 4
C		Ø8x30mm Wood Dowels X 8
D		Allen Wrench X 1
E		Straight Allen Wrench X 1


Other Tools Required
(Not Included)
.Phillips Screwdriver
.Flathead Screwdriver



PARTS IDENTIFICATION


-  Top panel (Attached Drawer box)
X 1
-  Left side panel
X 1
-  Right side panel
X 1
-  Bottom shelf
X 1

STEP 1



Unscrew the handle from inside of drawer and assemble it out side.



STEP 2



Do not tighten the bolts before finishing all steps.

STEP 3

Complete



Tighten all screws using an Allen Wrench or Straight Allen Wrench with a drill.

IMPORTANT: Be sure to use anti-tip kit included with this case piece.

Directions are included with the anti-tip kit. Follow as directed.



WARNING

Important Safety Notice

Dresser/chest can tip (fall over) when not used as intended. This could potentially result in serious injury or death. **Keep your children and others safe by following these simple rules:**

1. Do not allow climbing on any dresser/chest.
2. Do not leave drawers open when not in use.
3. Do not allow standing in drawers.
4. Do not allow hanging from drawers.
5. Do not allow standing on top of dresser/chest.
6. Do not place heavy objects in drawers.
7. Do not place heavy objects on top of the Dresser/chest which can be pulled down on top of your child.
8. To avoid head injury, do not allow your child to play underneath open drawers.
9. Hutches, mirror, etc. Must be securely fastened to the dresser according to the instructions enclosed with those items.
10. Always monitor your child's activity when in the nursery.

CARE INSTRUCTIONS



- A lacquer finish is used on this furniture to protect the wood. It is not waterproof, clean spills immediately. **Dust using a slightly damp cloth, making sure no standing water is left on the furniture.** **DO NOT use any household cleaners, citrus-based polishes, wood soaps, or oils; they can break down the natural lacquer finish.**



- Do not place furniture in direct sunlight. **natural solid wood furniture will naturally color as it ages, however direct sunlight dramatically speeds up the process.**




- **In natural wood furniture, the variations in texture and grain affect the finish, making it impossible to guarantee an exact match between two pieces of wood even though identical finishing processes are used. these differences in character are not defects, but variations that make each piece of furniture unique and beautiful.**

- Solid wood naturally expands and contracts. **In high humidity you may find that drawers can stick slightly. this will correct itself, and is not reason for concern.**



- Do not place furniture over heating or cooling vents. **Dramatic changes in temperature can cause the wood to split.**



- **If you place objects such as lamps or plants on your case pieces make sure to move them from time to time. there may be a slight discoloration where the object was. However by exposing it to light the color will catch up to the rest of the case.**



- **Plastic or foam footed items such as phones or clocks can damage this finish, use trivets under such items.**