




Assembly Instruction
ITEM NO #3263-100CD
COCKTAIL TABLE-Galleria Chrome






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.


Caution: Read before unpacking Assemble parts. Sharp exposed staples can cause injury. For your Protection, please remove any exposed staples used in packaging.

HARDWARE LIST

NO	SKETCH	DESCRIPTION	Q' TY
A		SUNK BOLT $\phi 1/4" \times 1/2"$	24PCS
B		ALLEN WRENCH	1PC
C		STRAIGHT ALLEN WRENCH	1PC

KD PARTS LIST

NO.	SKETCH	DESCRIPTION	Q' TY
1		TOP FRAME	1PC
2		BOTTOM FRAME	1PC
3		LEG	4PCS
4		GLASS TOP	1PC
5		GLASS SHELF	1PC



Step 1: Set up the top frame with two legs at one end.

Step 2: attached the bottom frame to these two legs which have been set up: and then fasten by bolt and allen wrench:Don` t fasten bolt too tightly until complete whole assembly.

Step 3: Attached the other end of bottom frame to the both the other two legs and end of top frame and then fasten all bolt by using allen wrench.

Step 4: Put both glass top and glass shelf to the top frame and bottom frame.

Notes: Straight Allen Wrench (C) is for use with a power drill.

MADE IN CHINA