















ASSEMBLY INSTRUCTIONS
ITEM NO :1524 Jackson Triple Power

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Make sure to read the instructions below before assembling your power sofa

The power cord (A) can be found attached to the power mechanism motor with a red wire tie. The power transformer(B) for the reading lights and wireless charging pod can be found attached to the bottom inside of the center dropdown table back with a red wire tie. The two read lights (C) can be found packaged together in the magazine pouch of the drop down table back .Remove them from there packaging and set them aside to be used later in step 4

NO TOOLS REQUIRED


PART LIST			POWER SOFA	POWER LOVESEAT WITH CONSOLE	POWER RECLINER
A	Power cord		1	1	1
B	Power Transformer for reading lights and wireless charging pod (pre attached)		1	/	/
C	Reading Light		2	/	/
D	LAF Back		1	1	/
E	Center Dropdown Table Back		1	/	/
F	RAF Back		1	1	/
G	Recliner Back		/	/	1
H	Console Back		/	1	/
I	Threaded Bolt (console back)		/	3	/
J	Wing Nuts (console back)		/	3	/
K	Plastic Washer		/	3	/
L	Sofa Body		1	/	/
M	Loveseat w/Console Body		/	1	/
N	Recliner Body		/	/	1

Step 1 Attach the KD backs : Position each KD back with the KD receiver positioned over the mechanism post on the body as pictured below .

***Check to assure both sides of the mechanism are positioned inside of the KD receivers on the back frame, pushing in a downward motion from the top of the back frame until a clicking sound is heard**

downward motion from the top of the back frame until a clicking sound is heard.

Care should be taken with the Sofa center dropdown table back as it may try and open during this step




Step 2*

Attach the leadwires found at the bottom of motion back to the leadwires at the rear of each motion seat, Red to Red & Yellow to Yellow. Make sure to close the clip locks to assure the connections will not come loose during use

The headrest leadwires are marked with yellow tape

The lumbar leadwires are marked with red tape



Power cord to be used in step 4

Step 3

*Attach outside backs across the bottom rear of each seat rail with the pre attached velcro

Step 4

*After attaching KD back as noted in steps 1,2 & 3, attach the power cord(A) to the power plug found at the rear of the left arm facing .


Step 5

*Loveseat Only: Attach the console back(H) with the hardware provided (L,J & K). Position the console back over the rear of the console. Align the holes and start all wing nuts before completely tightening. To prevent damage be careful not to overtighten

After assembly is complete your product should look as seen below.

1


SOFA/LOVESEAT W/CONSOLE /CHAIR



2

CHAIR/HOME THEATRE CONSOLE





Notes:

Do not plug the power cord and/or power transformer into a power outlet until your product has been completely assembled and in the location of its intended use

The two USB lights are intended to be used with the USB ports located in the center dropdown table back only. When not in use we recommend you store them in the magazine pouch or the hidden storage under the arm pads

To help prevent shock and or damage to your product only plug the power cord into a grounded outlet .The toggle switch at the rear of the arm will illuminate red when the product has power.

Read the operating instructions carefully before using your powered mechanized furniture


MADE IN CHINA

Operating Instructions for Jackson Triple Power Sku's

1524-53HP/54HP/50HP (Triple Power Sofa / Loveseat with Console/ Recliner)

Caution: Read the Important instructions below before operating your power mechanized product

Do not allow children to play on or operate this power mechanized product



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation

Open and Close Buttons

The open and close buttons will operate the function noted above by simply touching the button. To stop the mechanism in your desired position simply remove your finger from the button

Home Button

The Home button will close/return the headrest, lumbar and reclining mechanism to the closed position at the same time simply by pressing on the button. To stop the functions simply remove your finger from the button

Light Button

Sofa, Loveseat with Console & Recliner LAF Cup Holder Only: The light button controls the light in the cup holder and the base light found across the bottom front of your product. Touching the button will turn the light on and off.

Recliner LAF Cup Holder Only: The light button in the LAF cup holder turns the light on and off in both the LAF & RAF cup holder as well as the base light

Sofa & Loveseat with Console RAF Cup Holder Only: The light button controls the light in the cup holder only

1/2/2019 Rev

Jackson 1524