









Assembly Instruction for




COFFEE TABLE CTKM800CT/CTKM800CTE

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts .
4. Please put all parts on a non - abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST				
No	PARTS DESC.		CODE.	Q'TY.
A		TOP	PCTKM800CTTOP	1PC
B		FRAME LEG 1	PCTKM800CTLEG 1	1PC
C		FRAME LEG 2	PCTKM800CTLEG 2	1PC
D		L/R STRETCHER	PCTKM800CTSTR	2PCS

HARDWARE LIST				
No	HARDWARE DESC.		CODE.	Q'TY.
1		BOLT 1/4"x 38mm	PCTKM800CTHW	9PCS
2		SPRING WASHER Ø1/4"		9PCS
3		FLAT WASHER Ø1/4" Ø19x2mm		9PCS
4		ALLEN KEY 2-1/4"x4mm		1PC



Assembly completed