Assembly Instruction for

(D680-22) Counterstool-Beach/ Natural Metal LCL100CST

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1.We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2.Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4.Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST:						
NO.	DESCRIPTION	SKETCH	PART CODE.	QTY		
А	Back Frame		PLCL100CSTBFR	1		
В	Front Leg		PLCL100CSTLEG	1		
С	Seat		PLCL100CSTSEA	1		
D	Stretcher		PLCL100CSTSTR	2		

HARDWARE LIST:							
NO.	DESCRIPTION	SKETCH	PART CODE.	QTY			
1	Allen Bolt (1/4 x 3 1/2")	<u> </u>	PLCL100CSTHW	8			
2	Allen Bolt (1/4 x 2")	<u> </u>		4			
3	Lock Washer (1/4 x 2/5" x 2mm)			12			
4	Flat Washer (1/4 x 5/8" x 2mm)	0		12			
5	Wood Screws (1/8 x 2")	<i></i>		4			
6	Allen Key (1/8")			1			
7	Phillips Screwdriver (Not prvided)			1			







