




Assembly Instruction for

ROUND END TABLE








T.17820.ET

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts .
4. Please put all parts on a non - abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST				
No	PARTS DESC.		CODE.	Q'TY.
A		TOP		1
B		UPPER LEG FRAME	PT.17820 ETLEG1	1
C		LOWER LEG FRAME	PT.17820 ETLEG2	1

NOTE : Do not fully tighten any bolts until last step.

HARDWARE LIST				
No	HARDWARE DESC.		CODE.	Q'TY.
1		BOLT 5/16"x 38mm	PT.17820 ETHW	1
2		SPRING WASHER Ø5/16"		1
3		FLAT WASHER Ø5/16"		1
4		BOLT 1/4"x 85mm		4
5		SPRING WASHER Ø1/4"		4
6		FLAT WASHER Ø1/4"		4
7		ALLEN KEY		1

STEP 1





Assembly Instruction for

ROUND END TABLE

T.17820.ET

STEP 2



Completed step