

Assembly Instructions







COFFEE TABLE W/LIFT TOP

TCO100CTLT


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR COFFEE TABLE			
No.	PART DESC	CODE.	Q'TY
A	COFFEE TABLE W/LIFT TOP CHARCOAL - TABLE TOP		1
B	COFFEE TABLE W/LIFT TOP CHARCOAL - LEGS	PTCO100CTLLEG	4
C	COFFEE TABLE W/LIFT TOP CHARCOAL - BOTTOM SHELF	PTCO100CTLTSHF	1

HARDWARE LIST PACKED INSIDE BOX			
No.	HARDWARE DESC	CODE.	Q'TY
1	 ALLEN BOLT (5/16" x 50mm)	PTCO100CTLTHW	12
2	 SPRING WASHER (5/16")		12
3	 FLAT WASHER (5/16")		12
4	 ALLEN KEY (M4)		1
5	 CASTORS		4
6	 SCREW (#4 x 15mm)		16

STEP:1




Assembly Instructions

COFFEE TABLE W/LIFT TOP

TCO100CTLT

STEP:2



COMPLETED

