




Do not fully tighten bolts until assembly is complete.




ASSEMBLY INSTRUCTIONS

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.

Do not fully tighten bolts until assembly is complete.



A:2PCS




B:2PCS




C:2PCS



D:2PCS



E:1PC




F:1PC



G:2PCS



H:2PCS




I:1PC




J:36PCS




K:1PC




A



B



C



E

D