

ASSEMBLY INSTRUCTIONS

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



A:1PC



C:2PCS



D:1PC



G:6PCS H:6PCS



J:1PC



L:2PCS





M6*15





O:48PCS



I:4PCS




M:5PCS



P:1PC

Do not fully tighten bolts until assembly is complete.



Do not fully tighten bolts until assembly is complete.

