







CROSLEY

FURNITURE





Glass Shelving Unit CF6101




PART LIST

| A | B | C | D | E |
|---|---|---|--|---|
|  |  |  |  |  |
| Leg 4 pcs | Shelf Frame 4 pcs | Top Shelf Frame 1 pc | Glass Shelf 4 pcs | Top Glass Shelf 1 pc |


HARDWARE LIST


| 1 | 2 | 3 | 4 |
|---|---|---|---|
|  |  |  |  |
| 1/2"x 1/4" xD10 | | | |
| Bolt 42 pcs (Extra 2) | Allen Wrench 1 pc | Safety Strap Kit 1 set | Suction Cup Extra 2 pcs |

Step 1. Lay 2 legs(part#A) down on a flat surface. Insert top shelf frame(part#C) and all shelf frames(part#B) into brackets of the legs(part#A). Attach remaining 2 legs(part#A) by inserting brackets into top shelf frame(part#C) and shelf frames(part#B).





Step 2. Attach top shelf frame(part#C) and shelf frames(part#B) to the legs(part#A) by using bolts (part#1) and allen wrench(part#2). Bolts(part#1) will be inserted from the opposite direction for top shelf frame(part#C) only.
Note: Please do not fully tighten bolts until all of them are in place.









#1  x 40

#2  x 1

Step 3. Carefully turn unit upright. Install glass shelves(part#D) and top glass shelf(part#E) into the frame as shown below.



Step 4.

| | | | | | |
|---|---|---|---|---|---|
| 3 | A | B | C | D | E |
|  |  |  |  |  |  |
| SAFETY STRAP KIT 1SET | WALL ANCHOR 1PC | HOOK 2PCS | D8*1-1/2" SCREW 1PC | D10*1/2" BOLT 1PC | SAFETY WALL STRAP 1PC |

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.



1) Insert bolt(D) through hook(B) and using a philips screwdriver, attach it to the predrilled hole in the top shelf frame(part#C) of the frame.

2) Drill a 11/32" hole in the wall where this unit will be secured. The drilled hole will be at the same height as the hole in the top shelf frame(part#C) where the hook(B) was attached. Tap wall anchor (A) into the drilled hole.

3) Insert screw(C) through hook(B) into the wall anchor(A) using a philips screwdriver.

4) Insert safety wall strap(E) through both hooks(B) and tighten to secure.

Note: This item is not intended for clothing storage use.



WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!