

Version 1.1.0



MANHATTAN  
COMFORT

888-230-2225

*help@manhattancomfort.com*

*319 Ridge Rd, Dayton, NJ08810, New Jersey - United States*






***Rockefeller***



*62.99" Tv Stand*

*You can access the QR code to watch the assembly video!*







Prepare the room before starting the assembly, leaving it completely clean and the area in good condition to start the work.  
Use the cardboard of the packaging to separate and support the parts removed from the boxes.




x02

Recommended tools (not included)



## Parts




N°	Description	Qty.	Box
01	Base board	01	01
02	Left side panel	01	02
03	Left partition panel	01	02
04	Right partition panel	01	02
05	Right side panel	01	02
06	Front of the drawer	02	01
07	Left side panel of the drawer	02	02
08	Right side panel of the drawer	02	02
09	Rear panel of the drawer	02	01
10	Base of the drawer	02	01
11	Decorative apply	02	01
12	Feet	06	02
13	Central board	01	01
14	Central partition	01	01
15	Top board	01	01
16	Rear panel	01	01
17	Steel bar	01	01

## Hardware (box 2/2)


A = 24x



B = 22x



C = 18x



D = 18x




E = 18x



F = 14x




G = 26x




H = 20x




I = 08x




J = 02x




## Step 01

 $C = 18x$ 


Insert the hardware (C) into the parts 02, 03, 04, 05 and 14.




## Step 02

 $B = 04x$ 


Connect the parts 02 and 05 onto the part 01 with the hardware (B).




## Step 03

 $B = 02x$ 


Connect the part 03 onto the part 01 with the hardware (B).



## Step 04


 $B = 02x$ 

Connect the part 04 onto the part 01 with the hardware (B).




## Step 05


Pay attention to the correct position of the feet.  
The arrows refers to the correct hole to align the feet.



Rear side




Rear side




A = 24x

Connect the parts 12 onto the part 01 with the hardware (A).



## Step 06



J = 02x



Connect the part 17 onto the part 13 with the hardware (J).



H = 02x

Apply the hardware (H) onto the hardware (J).

Note that the screws must be facing the board.





## Step 07



D = 04x

Apply the hardware (D) into the part 13.









## Step 08


 $E = 04x$  $H = 04x$ 

Connect the part 13 onto the parts 03, 04 with the hardware E.




Apply the hardware (H) onto the hardware (E).


## Step 09

 $B = 04x$ 


Connect the part 13 onto the parts 02, 05 with the hardware (B).



## Step 10

 $B = 02x$ 


Connect the part 14 onto the part 13 with the hardware (B).



## Step 11

 $D = 06x$ 

Apply the hardware (D) into the part 15.



## Step 12







E = 06x



H = 06x

Connect the part 15 onto the parts 02, 05, 14 with the hardware E.



Apply the hardware (H) onto the hardware (E).


## Step 13



G = 26x

Connect the part 16 using the hardware (G).

Attention, the part 16 must be connected on the rear side!



## Step 14



D = 08x



Apply the hardware (D) into the part 06.



F = 06x

Before applying the part 11, observe if your product has the option of matching colors with the front of the drawer (part 06).

Connect the part 11 onto the part 06 with the hardware (F).



## Step 15





E = 08x

Connect the parts 07, 08 onto the part 06 with the hardware E.






H = 08x



Apply the hardware (H) onto the hardware (E).


**Step 16**

Apply the part 10 in the groove of the parts 07, 08 until the groove of the part 06.


**Step 17**

B = 08x



Connect the part 09 onto the parts 07, 08 with the hardware (B).




## Step 18

 $I = 04x$  $F = 04x$ 



Apply the hardware (I + F) into the groove of the part 06 as shown on detail.



## Step 19

 $I = 04x$  $F = 04x$ 

Apply the hardware (I + F) into the groove of the part 09 as shown on detail.



## Step 20

*Install the drawers fitting them into the slides fixed on the parts 03 and 04.*

